




Z1C~Z4C : FERRITE CORE
 X1M~X4M : TERMINAL STRIP
 Y1E~Y3E : ELECTRONIC EXPANSION VALVE COIL
 V2, V3, V5, V6, V11 : VARISTOR
 SA2 : SURGE ARRESTER
 FU1, FU2, FU3 : FUSE
 AC1, AC2 :
 U, V, W, X11A :
 E1, E2 :
 HR1, HR2 : CONNECTOR

MRM10, MRM20 : MAGNETIC RELAY
 R1T~R6T : THERMISTOR
 S2~S102 : CONNECTOR
 LED1~LED4 :
 LEDA : PILOT LAMP

L : LIVE
 N : NEUTRAL
 SW1 : FORCED OPERATION ON/OFF SW (SW1)
 SW2 : SELECT SW (SW2)
 SW3 : WIRING ERROR CHECK SW (SW3)
 SW4 : PRIORITY ROOM SETTING SW (SW4)
 SW5 : NIGHT QUIET MODE SETTING SW (SW5)

M1C : COMPRESSOR MOTOR
 M1F : FAN MOTOR
 L1R : REACTOR
 Q1L : OVERLOAD PROTECTOR
 PM1 : POWER MODULE
 PCB1, 2 : PRINTED CIRCUIT BOARD
 Y1R : REVERSING SOLENOID VALVE COIL
 SHEET METAL : TERMINAL STRIP FIXED PLATE