

INSTRUCTION MANUAL

ENGLISH Instructions

Place two AAA (R03) batteries. Mind your new remote control must point at air conditioner in order to control it.

Code set up by brand

1. Find your code in the code table. If it does not operate your equipment, try the second code, and continue until your equipment works correctly. If there are several codes like Hitachi 0118-0126 each code included replaces a different remote control
2. Press the "SELECT" key, the displayed code will flash. Enter the 4 digits code. The remote control confirms the code automatically. You can operate your air conditioner now.
3. After the air conditioner is "ON," try other function keys, if they do not work well, choose the next code until all the functions work.

Auto-search code set-up

- If your brand is not listed in the code table, please follow the following steps:
1. Press the "SELECT" key for 5 seconds and then release it, remote control shall enter auto-search, the code number flashes and increases. When the air conditioner receives the signal, and sends one buzzer, press any key to confirm.
 2. Try other function keys, if they do not work, repeat above steps until it works properly.

"Intelligent Cooling" / "Intelligent Heating"

In summer press "I-COOL" key only, the air conditioner will enter cooling immediately. In winter, press "I-Heat" key only, the air conditioner will enter heating immediately. The air conditioner will let the heating and cooling in a comfortable temperature automatically.

At the same time, you can adjust the temperature pressing "TEMP.+" / "TEMP.-" key.

Clock set up

1. Press the "CLOCK" key (9), clock signal flashes.
2. Press "time+/time-" key, adjust to the current time.
3. Press "CLOCK" key (9) again, clock signal shall stop flashing, the time setting finishes (If you do not press the "CLOCK" key, it automatically stops after 15 seconds).

Timer on

1. Press the "TIMER ON" key (7), time on LCD flashes.
2. Press "TIME+/-" key, and adjust it to automatically turn on your air conditioner.
3. Time on LCD will stop flashing after 15 seconds. Setting is complete.

Timer off

1. Press the "TIMER OFF" key (8), the time on LCD flashes.
2. Press "TIME+/-" key, adjust to automatically turn off.
3. Time on LCD will stop flashing after 15 seconds. Setting is complete.

PLEASE NOTE:

1. You can cancel timer pressing the "TIMER ON" or "TIMER OFF" key twice.
2. After timer setting is finished, your remote control must be placed towards your air conditioner.
3. If you wish to check the timer, you should press the "TIMER ON" or "TIMER OFF" key and the LCD will display the timer. After 5 seconds it will display current time.

Conversions between Celsius and Fahrenheit degree: Press the "C/F" key.

Sleep function

During summer, press the "SLEEP" key while it is in cool mode, the temperature will raise 1° F per hour in the first 2 hours and will be shut off by itself after 8 hours. In winter, press the "SLEEP" key while it is in heat mode, the temperature will lower 1° F per hour in the first 2 hours and will shut off by itself after 8 hours. After setting the sleep function place your remote towards the receiver of your air conditioner.

After the batteries are replaced it is not necessary to set the code again.

After pressing the "Enter" key, the code is displayed on LCD. After 5 seconds it displays time again
The manufacturer keeps the right to change any functions of product.

MANUALE DI ISTRUZIONI

ITALIANO Istruzioni

Inserire due pile AAA (R03).

Ricerca per marca

1. Se ci sono più modelli per lo stesso marchio, trovare quello che più si adatta al vostro condizionatore. Se nell'elenco è indicato un tratto fra due modelli, ad esempio Hitachi 0118-0126, ogni codice compreso fra questi numeri identifica un diverso telecomando.
2. Premere il tasto "SELECT", il codice lampeggerà sullo schermo. Inserire le 4 cifre del codice e, puntando verso il condizionatore, premere il tasto "POWER" per verificarne il corretto funzionamento.
3. In seguito, provare le funzioni dei vari tasti. Se non agiscono correttamente passare al codice successivo.

Autoricerca

- Se il vostro condizionatore non è citato fra le marche elencate sulla tabella codici:
1. Premere il tasto "SELECT" per 5 secondi e rilasciarlo mantenendo il telecomando sempre puntato verso il condizionatore. Il primo codice apparirà sullo schermo, quindi appariranno in successione nuovi codici. Appena il condizionatore si avvierà, emettendo un segnale acustico, premere un qualunque tasto per fermare la ricerca.
 2. Provare le funzioni dei vari tasti. Se non agiscono correttamente continuare l'autoricerca.

"Intelligent Cooling" / "Intelligent Heating"

I tasti "I COOL" e "I HEAT" portano automaticamente il vostro condizionatore alla temperatura desiderata.

Regolazione dell'orologio

1. Premere il tasto (9) "clock": L'ora lampeggerà.
2. Premere il tasto "time+/time-" per regolare l'orologio.
3. Premere nuovamente il tasto "clock" per confermare l'ora selezionata (si fermerà automaticamente dopo 15 secondi).

Timer

(Si può scegliere di regolare l'accensione oppure lo spegnimento)

1. Premere il tasto "TIMER ON" rivolgendo il telecomando verso il condizionatore. Il display inizierà a lampeggiare.

2. Premere il tasto "TIME+/-" e regolarlo per impostare l'orario dell'accensione automatica.
3. Trascorsi 15 secondi il timer smetterà di lampeggiare e tornerà alla funzione "orologio".

Spegnimento funzione timer

1. Premere il tasto "TIMER OFF"; sul display l'ora lampeggia.
2. Premere il tasto "TIME+/-"; per regolare l'ora di spegnimento.
3. Sul display, l'ora scelta smetterà di lampeggiare dopo 15 secondi.

Si può cancellare il timer premendo 2 volte il tasto "TIMER ON" o "TIMER OFF".

Una volta regolato il timer il telecomando deve rimanere orientato verso il condizionatore.
Per passare da Celsius a Fahrenheit premere il tasto "C/F".

Funzione "sonno" estate/inverno

Premere il tasto "SLEEP" e la temperatura aumenterà di un grado ogni ora per 2 ore. Si spegnerà non appena trascorse 8 ore.
In modalità riscaldamento, premere il tasto "SLEEP"; la temperatura diminuirà di 1 grado per le successive 2 ore e il condizionatore si spegnerà una volta trascorse 8 ore.
Il telecomando deve essere orientato verso il condizionatore.

Questo telecomando conserva i codici inseriti, anche senza pile.
Il produttore si riserva il diritto di modificare le caratteristiche del prodotto senza preavviso.

COMPATIBLE DEVICE



SUPERIOR Airco



VISIT OUR
WEBSITE TO
DISCOVER
BRAND NEW
PRODUCTS

Brand	Model Code
AERMEC	105
ALPIN	0252,0253,0764,1277,1789
ARISTON	107
ARTEL	232
AUCMA	0288-0296,0462,1313,1998
AUX	0297-0300,0451,0474,0475,0812,1987
BANSHEN	0264,1288,1800
BELAIR IRRADIO	297,829
BION	026
BOERKA	0383,0434,0436,0437,1407,1972
BRAVO	107
CARRIER	007,0203-0209,0456-0458,0482-0486,0563-0565
CELESTAR	829
CHANGHONG	0301-0308,0813,1843
CHIGAO	0379-0382,0489,0515,1403,1916
CHIGO	964
CHOFU	0184-0187,1209,1723
CHUNLAN	0345-0350,0450,0453,1373
CLIMAX	308,354
CORONA	0155-0163,0459,1180,1995
CONROWA	0377,1401,1913
CONSUL	0463,0975
DAEWOO	0203-0209,0406,0715,1942
DAIKIN	0171-0183,0566,0577,0685,1707,695
DAITSU	266
DE LONGHI	107,192,197,232,282
DILOC	026
DOCTOR	0221,0449,1245,1985
DONGBAO	0355-0361,1385,1891
DONGXINBAO	0413,0925,1654
ECOFLAM-CLIMA	107
EKOS	107
ELECTROLUX	0216-0220,0569,1245,1752
FEDDERS	0498,0499,0528
EMMETI	266
FERROLI	829
FRESTECH	0277,0519,0520,089
FUJITSU	0127-0137,0464,0552-0554,1152
FUNAI	0430,0481,1505,1966
GALANZ	0371,0372,0521,0883,1908,829
GALLETTI	829
GENERAL	0128-0136,0639,0976,1161
GUQIAO	0244,0291,1268,1827
GLEE	0398,0399,0910,1935
GOLDSTAR	0201,0466-0469,0979,1737
GREE	0309-0316,0482,0512,0513
HAIER	0266-0272,0453-0455,0778
HYPER	829
HISENSE	0332-0335,0517,0847,1359,1868


Brand	Model Code
HITACHI	0118-0126,0630,1145
HUABAO	0336-0344,1360,1878
HUAKE	0408,0920,1944
HUAMEI	0402,0460-0465,1426,1999
HUALING	0317-0325,0452,0964
HUIFENG	0370,0882
HUIKANG	0368,0441-0443,1392,1979
HYUNDAI	0202,0433,0480,1226,1969
IDEAL STANDARD	232
IRRADIO	829
JDC	0373,0440,0952,1909
JIANGNAN	0432,1456
JINDA	0414,0926,1950
JINSONG	0389-0391,0446-0448,1984
JOHNSON	0245,0492,1269,1516
JOYCARE	297
KANGLI	0374,0375,1399,1910
KELON	0282-0287,0473,0485-0488
KENWOOD	197
KLIMATAIR	0225,0226,0452,0737,1761
KOLIN	0416-0418,1441,1952
KONKA	0397,0457-0459,1933
LENNOX	197
LG	0197-0200,0514,1026,1733
LIANGYU	0233,0451,0745,1257
LITTLE DUCK	0015-0020,0530,1043
LOREN-SEBO	0255,0471,0472,0767
MACQUAY	0234-0237,0465,0746,1773
MEDIASONIC	232
MICOM	0415,0927,1951
MIDEA	0260-0265,0526,1289,1976
MITSUBISHI	0001-0045,0476-0479,0522,0523,0568,0582,1502,829
NEWTRON	282
NORITZ	0431,1455
ORIEME	369,829
PANASONIC NATIONAL	0138-0154,0483,0490-0492,0653,1507
PANDA	0378,0890
PHILCO	0210,0211,0487,0488,1746
PROTON	0421-0423,0933,1958
RAYBO	0362-0367,1386,1898
RAP	829
RHOS	308
RHOSS	107
RIELLO	266
ROWA	0369,0438,0439,0494,0527,0531,1393
SAUNLERO	107
SABRO	0435,0506-0508,1018,1971
SAIJO DENKI	0212-0215,0724,1750
SAMPO	0424-0426,1448,1961

Brand	Model Code
SAMSUNG	0188-0196,0516,0518,0700,1726
SANYO	0046-0095,0558,0529,0530,1582
SASUKI	0254,0470,0766,1494
SEKOM	829
SHANGLING	0384-0388,0444,0445,1980
SHANXING	0392,0449,1416,1985
SHARP	0096-0106,0525,0609,1640
SHENGFENG	0376,0480,1504,1912
SHINCO	0351-0354,0454-0456,1887
SHINELCO	026,297
SHUANGLU	0376,0404-0407,0480,1941
SHUAIKANG	0288,0800
SOKAI	829
SONGGE	0428,0429,1453,1964
SOVA	0409,0410,0921,1434
STAR CLIMA	964
SUMMER	0427,1451
SUNDRUNG	0257,0505,1017,1793
SUSHIMA	829
SWAN	0434,0477,0516,0524,0946
TADIRAN	0246-0251,0758,1275
TASAKI	219
TATUNG	0419,0420,0932,1955
TCL	0273-0281,0476,0493,0570,0786,1305,829
TECO	0256,0473-0475,1792
TENSAI	107
TIANDI	0415,1439
TOYAMA	026
TOSHIBA	0107-0117,0479,0561,0562,0489,1001,1643
TRANE	0227-0232,0739,1768
UNI-AIR	0222-0224,0450,0734,1986
UNICAL	829
UNIVERSAL AC	445
VORTICE	231
VORTIS	297
WAN BAO	0138-0152,0666,0995,1177
WEILI	0393-0396,0907,1420,1929
WHIRLPOOL	0164-0170,0502,0677,1760,282
WHITE-WESTINGHOUSE	107
WINIA	0481,0550,0993
X BASE	266
XILENG	0411,0412,0924,1947
XINLE	0400,0401,0913,1425,1936
YANGZI (YAIR)	0403,0915
YINYAN	258,259,326-331,0478,0838
YORK	0107,0238-0243,0573,0750,1266
ZHEN BAO	0129-0137,1151,1488,1664
ZOMIX	829
ZOOMIX	297

Supported Brands:

A AERMEC, ALPIN, ARISTON, ARTEL, AUCMA, AUX
B BANSHEN, BELAIR IRRADIO, BION, BOERKA, BRAVO
C CARRIER, CELESTAR, CHANGHONG, CHIGAO, CHIGO, CHOFU, CHUNLAN, CLIMAX, CORONA, CONROWA, CONSUL
D DAEWOO, DAIKIN, DAITSU, DE LONGHI, DILOC, DOCTOR, DONGBAO, DONGXINBAO
E ECOFLAM, ECOFLAMCLIMA, EKOS, ELECTROLUX, EMMETI
F FERROLI, FRESTECH, FUJITSU, FUNAI
G GALANZ, GALLETTI, GENERAL, GUQIAO, GLEE, GOLDSTAR, GREE
H HAIER, HYPER, HISENSE, HITACHI, HUABAO, HUAKE, HUAMEI, HUALING, HUIFENG, HUIKANG, HYUNDAI
I IDEAL STANDARD, IRRADIO
J JDC, JIANGNAN, JINDA, JINSONG, JOHSON, JOYCARE
K KANGLI, KELON, KENWOOD, KLIMATAIR, KOLIN, KONKA
L LENNOX, LG, LIANGYU, LITTLE DUCK, LOREN-SEBO
M MACQUAY, MEDIASONIC, MICOM, MIDEA, MITSUBISHI
N NEWTRON, NORITZ
O ORIEME
P PANASONIC NATIONAL, PANDA, PHILCO, PROTON
R RAYBO, RAP, RHOS, RHOSS, RIELLO, ROWA
S SAUNLER, SABRO, SAIJO DENKI, SAMPO, SAMSUNG, SANYO, SASUKI, SEKOM, SHANGLING, SHANXING, SHARP, SHENGFENG, SHINCO, SHINELCO, SHUANGLU, SHUAIKANG, SOKAI, SONGGE, SOVA, STAR CLIMA, SUMMER, SUNDRUNG, SUSHIMA, SWAN
T TADIRAN, TASAKI, TATUNG, TCL, TECO, TENSAI, TIANDI, TOYAMA, TOSHIBA, TRANE
U UNI-AIR, UNICAL, UNIVERSAL AC
V VORTICE, VORTIS
W WAN BAO, WEILI, WHIRLPOOL, WHITE-WHE-STING HOUSE, WINIA
X X BASE, XILENG, XINLE
Y YANGZI (YAIR), YINYAN, YORK
Z ZHEN BAO, ZOMIX, ZOOMIX

Made in China



2x1.5V LR03 AAA/AM4
Batteries not included
Pile non incluse

Instructions booklet inside. Languages:
English-Italiano-Français-Español-Português-Deutsch

